

Spare parts list

Cookers
2213

PNC	ELC	Brand	Model	Market
943006001	00	Electrolux	EHE33X	ID - MY - PH - SG - TH - VN

	Electric, solid hotplates / tubular rings
Electrolux	Publication-No. 599744690 2011/08/10 7TH



SPARE PARTS LIST
Electric Solid hotplates/tubul
2213

Item	PNC	ELC	Brand	Model	Market
A	943006001	00	Electrolux	EHE33X	S.E.A.


Electrolux Thailand Co.,Ltd.
1910 Electrolux Building
New Petchburi Rd.
Bangkapi
Huaykwang
Bangkok , 10310
Tel : +662 725 9000

Publication-No.
110705

Electric Solid
hotplates/tubul

Model : EHE33X
PNC : 943006001

Ex. View Drawing
Complete Assembly




Item	PNC	ELC	Brand	Model	Market
A	943006001	00	Electrolux	EHE33X	S.E.A.

Pos.	Part No.	Description
01	TH-0005/PG	Ego hot plate 1500W 240V
02	TH-0005/PF	Ego hot plate 1000W 240V
03	TH-0001/ID	Ptd top plate - 2 hot plate
04	H2-0219/AP	Screw M4x10mm washer head
05	TH-0005/UF	Hot plate protection cover - big
06	S1-0059/FE	Washer out M4 - star washer
07	H6-0037/AB	Nut hex M4 7mm
08	TH-0005/UJ	Hot plate protection cover - small
09	TH-0018/AJ	Screw MSP 3x16
10	TH-0010/CB	Porcelain connector 15A 2 way
11	S1-0058/BD	Screw TPG Pan 4mmX6mm BT
12	TH-0005/UA	Sparker clip (HZ 196)
13	TH-0010/FA	Power cord relief
14	TH-0030/ZC	Power cord assy 180°C
15	TH-0018/CA	Brass nut hex 10mmxM5xL5mm
16	S1-0059/FE	Washer out M4 - star washer
17	TH-0002/DA	Bottom plate -Domino
18	S1-0058/BF	Screw TPP 3x6A
19	TH-0005/UI	Switch cover - long
20	TH-0005/QA	Ego switch 41.41723.000
21	TH-0015/CA	GASKET FOR PLATE SWITCH(EHE33X)
22	TH-0018/CB	Brass nut hex 14mmxM12xL2mm
23	TH-0016/BY	Knob - electrolux (ETU KNOB)
24	TH-0030/AN	Lamp assy 100 k ohm w/terminal
25	TH-0010/BA	Lamp cover

Model : EHE33X
PNC : 943006001

Wirring Diagram



Exploded view no.: P94300600100
P09493062715

Matrix	PNC	ELC	ProdDate	Model
A	943006001	00	20110601	EHE33X

Pos	Part No.	Matrix	Description
------------	-----------------	---------------	--------------------